


SR 540 EX

Spare parts / Accessories



No.	Description	Ordering No
1.	Face shield SR 540 EX	
2.	Flat gasket	R06-0506
3.	Breathing hose	R06-0501
4.	O-ring	R06-0202
5.	Face seal	T06-0504
6.	Set of valves SR 540 EX	R06-2004
6a.	Exhalation membrane 1 pc.	-
6b.	Cover exhalation valve 1 pc.	-
7.	Visor set PC (incl. closing panel, right + left)	R06-0502
8.	Visor PC, 10 pcs	R06-0507
9.	Visor set PETG (incl. closing panel, right + left)	T06-0502
10.	Head harness	R06-0511
11.	Sweatband	R06-0504
12.	Cleaning wipes. 50/box	H09-0401